

## **67-72 Speaker Brackets**

### **PN 6772-C10-SB69**

#### **Recommended tools**

- Plastic pry tool

#### **Included parts**

- Speaker Bracket (2)

#### **Installation**

1. Start with the top flange and rotate into place with the small 90-degree tab located at the cab floor. **(Image 1)**



**Image 1**



2. Tuck the ½-inch side flange closest to the door underneath the weatherstripping. The ¾-inch side flange at the back of the cab can be attached with double sided tape, epoxy, or screws. **(Image 2)**

**Image 2**

3. If desired the small tab at the bottom of the bracket can be installed with a sheet metal screw but is not required. **(Image 3)**



**Image 3**

4. We do recommend installing sound deadening or insulation behind the speaker bracket to project the sound of the speakers out towards the passengers.

5. Pat yourself on the back and grab a drink, you have successfully completed your install!!!